

私有雲與電腦同步資料


使用 SyncBackFree

私有雲要如何與電腦同步資料？一般市面上提供很多同步軟體都可以達到這一個目的，我們未您介紹的式一個免費又簡單的同步軟體[SyncBackFree]，這套軟體如何與私有雲同步的說明如下：


1. 下載免費的[SyncBackFree]程式。
2. 下載後進行安裝。




3. 開啟[SyncBackFree]



4. 選擇要同步的電腦資料夾與私有雲位置（網路位置請參考[Samba (Windows OS)]設定，再進行選取動作）。



5. 按下「同步」，確認動作正確後再按下「開始」進行同步作業。



6. 同步作業完成。



其他同步設定，可以進入程式中的「同步設定」進行修改。

The screenshot shows the '同步設定' (Sync Settings) dialog box. It is divided into several sections:

- 選擇變數 (Select Variables):** Includes buttons for '<- 雙向 ->' (Two-way), '鏡像 ->>' (Mirror), '更新 ->' (Update), and '自訂' (Custom). Each button has a corresponding description of its function.
- 錯誤處理 (Error Handling):** Includes buttons for '忽略' (Ignore) and '彈出視窗' (Pop up window), and a dropdown menu for '完成後' (After completion).
- 刪除處理 (Deletion Handling):** Includes buttons for '常駐' (Permanent), '資源回收筒' (Recycle bin), and '版本控制' (Version control).
- 配置 (Configuration):** A sidebar on the right with '分類' (Category) and '動作' (Action) columns, containing icons for file operations like copy, paste, delete, and sync.

'確定' (OK) and '取消' (Cancel) buttons are at the bottom right.

From: <http://wiki.myakitio.com/> - MyAkitio Wiki

Permanent link: <http://wiki.myakitio.com/zh-tw:sync>

Last update: 2013/04/01 08:09

