

# 私有雲與電腦同步資料


## 使用 SyncBackFree

私有雲要如何與電腦同步資料？一般市面上提供很多同步軟體都可以達到這一個目的，我們未您介紹的式一個免費又簡單的同步軟體[SyncBackFree]，這套軟體如何與私有雲同步的說明如下：


1. 下載免費的[SyncBackFree]程式。
2. 下載後進行安裝。




3. 開啟[SyncBackFree]



4. 選擇要同步的電腦資料夾與私有雲位置（網路位置請參考[Samba (Windows OS)]設定，再進行選取動作）。



5. 按下「同步」，確認動作正確後再按下「開始」進行同步作業。



6. 同步作業完成。



其他同步設定，可以進入程式中的「同步設定」進行修改。

The screenshot shows the 'Sync Settings' (同步設定) dialog box. It is divided into several sections:

- 選擇變數 (Select Variable):** Contains four buttons: '<- 雙向 ->' (Two-way), '鏡像 ->>' (Mirror), '更新 ->' (Update), and '自訂' (Custom). Each button has a corresponding description of its function.
- 錯誤處理 (Error Handling):** Includes buttons for '忽略' (Ignore) and '彈出視窗' (Pop up window), and a dropdown menu for '完成後' (After completion).
- 刪除處理 (Deletion Handling):** Includes buttons for '常駐' (Permanent), '資源回收筒' (Recycle bin), and '版本控制' (Version control).
- 配置 (Configuration):** A sidebar on the right with a '分類 動作' (Category Action) section containing icons for file operations like copy, paste, delete, and sync.

'確定' (OK) and '取消' (Cancel) buttons are at the bottom right.

From: <http://wiki.myakitio.com/> - MyAkitio Wiki

Permanent link: <http://wiki.myakitio.com/zh-tw:sync>

Last update: 2013/04/01 08:09

